

Návod na použitie trezora Instructions for use of room safe

1. Zadáte prvotné heslo 0000, potvrdíte heslo stlačením tlačidla „B“, otočte otočný uzáver v smere hodinových ručičiek do vodorovnej polohy.
 2. Pre zmenu hesla je potrebné stlačiť červené tlačidlo nachádzajúce sa na vnútornej strane dverí pod krytom na batérie.
 3. V priebehu 15 sekúnd zadajte štvor až osemmiestne číslo podľa Vášho výberu. Potvrdíte Vaše zadanie stlačením tlačidla potvrdenie „B“.
 4. Zatvorte dvere trezora a otočte otočný uzáver dverí proti smeru hodinových ručičiek do zvislej polohy.
 5. Ak zadáte nesprávne heslo trikrát po sebe, nebude možné po dobu cca 20 sekúnd vykonať žiadne zadanie.
-
1. Enter the initial code 0000, confirm the code by pressing the button “B”, rotate the cap clockwise to a horizontal position.
 2. To change the password, you need to press the red button on the inner side of the door under the battery cover.
 3. Within 15 second enter the four – to eight- digit number of your choice. Confirm your entry by pressing the confirmation button “B”.
 4. Close the door of the safe and rotate the cap to counterclockwise to a vertical position.
 5. If you enter the wrong password three times, so it is not possible for about 20 seconds to make any option.